


FESCOLO



FESCOLO

[Fescolo Pneumatic Co.,Ltd.](#)

Sales Manager: Jeffrey Bu

Postal code: 315100

Tel.: +86 574 89258005

Cell phone.: +86 0 15057491870

Email: sales@fescolo.com

Web.: www.fescolo.com

Add.: #98 Tiangao Lane, Yinzhou, Ningbo, Zhejiang, China

PIPE FITTING

Fescolo Pneumatic Co.,Ltd.

Company Profile

Fescolo pneumatic Co., Ltd. , found in 2001, which specializes in pneumatic products such as air cylinders, solenoid valves, pneumatic control valves, filter regulators, air hose, fittings and so on. We have an excellent technical research department, first-class production technology and equipments. All our workshops are in accordance with 6S principles. At present, we have 18 production lines, more than 2,000 production equipments, annual turnover of more than 20 million US dollars.

Until now, our customers are more than 80 countries around the world. Our major products include air cylinders, solenoid valves, pneumatic control valves, filter regulators, air hoses and fittings. The applications involve industrial automation, medical treatment, sanitary ware, automobile manufacturing, wire and cable, horticulture and agricultural irrigation etc. Furthermore, we accept ODM and OEM customization services, and can design logo and label for our customers.

Our chief technical engineer, Antonio Bonifazi from Italy, had worked as a technical engineer in Aigiro Group and NSG Group for many years. He has fruitful experience and unique technology in mechanical automation industry. Each product from Fescolo will go through 3 inspections at least before shipping, in order to guarantee every product you receive is perfect. The raw materials we use are the best and latest, never recycled or old materials. Basically, all our molds are developed and designed by ourselves, which ensures the stability of product quality. At present, 70% workshops realize automatic production, which greatly increases the production capacity. Compared with last year, the annual production capacity has increased by more than 50%. In addition, there are a large number of workblanks and semi-finished products available in stock. From order confirmation to delivery, usually it takes only 3~10 working days. We have stable freight forwarders by sea, air and train, so that we can deliver the goods to our customers with the best price and service.

Most of our products includes a one-year or 6-month warranty. Many replacement parts are available in stocked they can be shipped within 3days. Our technical sales team experienced and reliable can provide best services from pre-sales to after-sale, as well as technical support and consultancy. We are on a mission to create a green and healthy production environment for our employees, to provide our customers with professional and efficient services, energy-saving and stable quality products.

Warmly welcome and opening up the boundaries of our communication. Sincerely, we are looking forward to your cooperation in the near future. FESCOLO, your trusted partner forever.



Table of contents

1 Brass Fittings And Connectors

🔧 AB-003 Male to female elbow -----	06
🔧 AB-024 Nut lock fitting -----	07
🔧 AB-025 Male brass elbow -----	07
🔧 AB-026 Male to female elbow -----	07
🔧 AB-027 Male to female T branch -----	08
🔧 AB-028 M-F Tee branch -----	08
🔧 AB-029 Female Tee branch -----	08
🔧 AB-030 Female cross -----	09
🔧 AB-031 Male Tee branch -----	09
🔧 AB-032 Male brass nipple -----	09
🔧 AB-033 Male brass reducer -----	10
🔧 AB-034 M-F brass connector -----	10
🔧 AB-035 F-M brass reducer -----	10
🔧 AB-036 Inner Hex. plug -----	11
🔧 AB-038 Hex head plug -----	11
🔧 AB-039 Female brass socket -----	11
🔧 AB-044 Female 4ways Y branch -----	12
🔧 AB-045 Female 3ways Y branch -----	12
🔧 AB-046 F-M 3ways Y branch -----	12
🔧 AB-047 Male hose barb elbow -----	13
🔧 AB-048 Male hose barb -----	14
🔧 AB-050 Female hose barb -----	14
🔧 AB-053 Hose barb nipple -----	14
🔧 AB-054 Hose barb Tee branch -----	15
🔧 AB-055 Hose barb Y branch -----	15
🔧 AB-056 Hose barb cross -----	15
🔧 AB-057 Brass ferrule fitting -----	16
🔧 AB-074 Brass ferrule elbow -----	16
🔧 AB-075 Brass swivel connector -----	16

2 Brass Fittings With Nickel Plated

	AB-001N Brass male elbow	18
	AB-002N Brass female elbow	19
	AB-003N Brass F-M elbow	19
	AB-007N Brass Tee branch	19
	AB-008N Brass female Tee branch	20
	AB-009N Brass F-F-M Tee branch	20
	AB-010N Brass F-M-F Tee branch	20
	AB-011N Brass M-F-M Tee branch	21
	AB-032N Male double nipple	21
	AB-033N Male reducer nipple	21
	AB-034N Brass F-M adapter	22
	AB-035N Brass F-M reducer	22
	AB-036N Brass Hex.socket plug	22
	AB-037N Brass Hex.socket plug	23
	AB-039N Brass female socket	23
	AB-048N Brass hose barb	23
	AB-086N Extended F-M adapter	24

3 Brass Rapid Fitting With Nickel Plated

	RPC Male straight	26
	RPL Male swivel 90°elbow	27
	RPLW Male 90°elbow	27
	RPU Straight fitting	27
	RPM Bulkhead straight	28
	RPV 90°elbow	28
	RPE Tee branch	28
	RPB Male Tee branch	29
	RPB-G Male Tee branch with o ring	29
	RPH Male banjo fitting	29
	RPZA Cross fitting	30

4 Brass Ferrule Compression Fitting

	FPB Brass ferrule compression male Tee branch	32
	FPC Brass ferrule compression male straight	33
	FPCF Brass ferrule compression female straight	33
	FPD Brass ferrule compression male Tee branch	33
	FPE Brass ferrule compression Tee branch	34
	FPL Brass ferrule compression male elbow	34
	FPM Brass ferrule compression bulkhead straight	34
	FPU Brass ferrule compression straight	35
	FPV Brass ferrule compression elbow	35
	FPZA Brass ferrule compression cross	35

5 Carbon Steel Connector

	CS-032 Steel double nipple	36
	CS-034 Steel F-M adapter	37
	CS-035 Steel F-M reducer	37
	CS-036 Steel Hex.socket plug	37
	CS-037 Steel Hex.socket plug	38
	CS-038 Steel Hex.plug	38
	CS-039 Steel female socket	38
	CS-041 Steel bulkhead fitting	39
	CS-8054 Female five ports	39
	CS-8057 Five ports adpater	39
	CS-8059 Male five ports	40
	CS-8060 Female six ports	40
	CS-8061 Male six ports	40
	CS-8069 Male six ports	41
	CS-8071 Steel tri-branch 90°	41
	CS-8072 Steel Tee branch	41
	CS-8073 Steel Tri-branch 120°	42
	CS-8074 Steel elbow with nut	42

 CS-8077 Steel round elbow	42
 CS-8078 Steel long Tee branch	43
 CS-8081N Steel long tri-branch 120°	43
 CS-8081 Long tri-branch 120° with nut	43
 CS-8083N Steel elbow with nut	44
 CS-8083 Steel long elbow	44
 CS-8087 Steel Arc elbow	44
 CS-8092 Steel tri-branch with nut	45

6 Check Valve (Non-Return Valve)

 CV-01 One way check valve	46
 CV-03 Brass check valve	47
 CV-04 Brass check valve	47
 CV-05 Brass check valve	47
 CV-06 Brass check valve	48
 CV-07 Brass foot valve	48
 CV-07F Brass foot valve with mesh	48
 CV-07FB Brass foot valve with mesh	49
 CV-08 Brass check valve	49
 CV-09 Brass foot valve	49
 CV-10 Brass exhaust valve	50
 CV-12 Steel check valve	50
 YF-25 Brass Y drainer	50

7 Copper Pipe Fitting For Cooling And Air-condition System

 AC-001 Copper cap	52
 AC-002 Copper socket	52
 AC-003 Copper reducer	53
 AC-004 Copper U elbow	53
 AC-005 Copper U elbow	53
 AC-006 Copper U elbow socket	54

 AC-007 Copper plug-in U elbow	54
 AC-008 Copper U elbow	54
 AC-009 Copper 45°elbow socket	55
 AC-010 Copper 45°elbow socket	55
 AC-011 Copper 90°elbow	55
 AC-012 Copper 90°elbow socket	56
 AC-013 Copper 90°elbow socket	56
 AC-014 Copper 90°elbow socket	56
 AC-015 Copper reducing 90°elbow	57
 AC-016 Copper Tri-branch	57
 AC-017 Copper Tri-branch	57
 AC-018 Copper Tee branch	58
 AC-019 Copper reducing T branch	58
 AC-020 Copper reducing T branch	58
 AC-021 Copper reducing T branch	59
 AC-022 Copper cross	59
 AC-023 Copper reducing cross	59
 AC-024 Copper curving pipe	60
 AC-025 Copper bridge	60
 AC-026 Copper bridge T branch	60
 AC-027 Copper Tee branch	61
 AC-028 Copper reducer	61
 AC-029 Copper female plug	61
 AC-030 Copper plug	62

8 Others

 AC-B Brass air chunk	63
 AC-C-B Brass air chunk with clamp	64
 AC-C-C Steel air chunk with clamp	64
 BF-M Brass male filter	64
 UJ-MF-02 Universal joint	65

How to order:

AB - 003 - 1/4 - 1/4

● Brass fitting

● Type

● Female thread

1/8

1/4

3/8

1/2

3/4

1

● Male thread

1/8

1/4

3/8

1/2

3/4

1

AB-003

Male to female elbow



Model	Female thread	Male thread
AB-003-1/8-1/8	1/8	1/8
AB-003-1/4-1/4	1/4	1/4
AB-003-3/8-3/8	3/8	3/8
AB-003-1/2-1/2	1/2	1/2
AB-003-3/4-3/4	3/4	3/4

AB-024


Nut lock fitting



Model	Male thread	Hose O.D. x I.D.
AB-024-1/8-6x4	1/8	6x4
AB-024-1/4-8x5	1/4	8x5
AB-024-3/8-10x6.5	3/8	10x6.5
AB-024-1/2-12x8	1/2	12x8
AB-024-3/4-14x10	3/4	14x10
AB-024-1-16x12	1	16x12

AB-025

Male brass elbow



Model	Male(1) thread	Male(2) thread
AB-025-1/8-1/8	1/8	1/8
AB-025-1/4-1/4	1/4	1/4
AB-025-3/8-3/8	3/8	3/8
AB-025-1/2-1/2	1/2	1/2
AB-025-3/4-3/4	3/4	3/4

AB-026

Male to female elbow



Model	Female thread	Male thread
AB-026-1/8-1/8	1/8	1/8
AB-026-1/4-1/4	1/4	1/4
AB-026-3/8-3/8	3/8	3/8
AB-026-1/2-1/2	1/2	1/2
AB-026-3/4-3/4	3/4	3/4

AB-027
Male to female T branch



Model	Female thread	Male thread
AB-027-1/8-1/8	1/8	1/8
AB-027-1/4-1/4	1/4	1/4
AB-027-3/8-3/8	3/8	3/8
AB-027-1/2-1/2	1/2	1/2
AB-027-3/4-3/4	3/4	3/4

AB-030
Female cross



Model	Female thread	Male thread
AB-030-1/8	1/8	
AB-030-1/4	1/4	
AB-030-3/8	3/8	
AB-030-1/2	1/2	
AB-030-3/4	3/4	

AB-028
M-F Tee branch



Model	Female thread	Male thread
AB-028-1/8-1/8	1/8	1/8
AB-028-1/4-1/4	1/4	1/4
AB-028-3/8-3/8	3/8	3/8
AB-028-1/2-1/2	1/2	1/2
AB-028-3/4-3/4	3/4	3/4

AB-031
Male Tee branch



Model	Male(1) thread	Male(2) thread
AB-031-1/8-1/4	1/8	1/4
AB-031-1/4-3/8	1/4	3/8
AB-031-3/8-1/2	3/8	1/2
AB-031-1/2-3/4	1/2	3/4

AB-029
Female Tee branch



Model	Female thread	Male thread
AB-029-1/8	1/8	
AB-029-1/4	1/4	
AB-029-3/8	3/8	
AB-029-1/2	1/2	
AB-029-3/4	3/4	

AB-032
Male brass nipple



Model	Female thread	Male thread
AB-032-1/8		1/8
AB-032-1/4		1/4
AB-032-3/8		3/8
AB-032-1/2		1/2
AB-032-3/4		3/4

AB-033
Male brass reducer



Model	Male(1) thread	Male(2) thread
AB-033-1/8-1/4	1/8	1/4
AB-033-1/4-3/8	1/4	3/8
AB-033-3/8-1/2	3/8	1/2
AB-033-1/2-3/4	1/2	3/4

AB-034
M-F brass connector



Model	Female thread	Male thread
AB-034-1/8-1/8	1/8	1/8
AB-034-1/4-1/4	1/4	1/4
AB-034-3/8-3/8	3/8	3/8
AB-034-1/2-1/2	1/2	1/2
AB-034-3/4-3/4	3/4	3/4

AB-035
F-M brass reducer



Model	Female thread	Male thread
AB-035-1/8-1/4	1/8	1/4
AB-035-1/4-3/8	1/4	3/8
AB-035-3/8-1/2	3/8	1/2
AB-035-1/2-3/4	1/2	3/4

AB-036
Inner Hex. plug



Model	Female thread	Male thread
AB-036-1/8		1/8
AB-036-1/4		1/4
AB-036-3/8		3/8
AB-036-1/2		1/2
AB-036-3/4		3/4

AB-038
Hex head plug



Model	Female thread	Male thread
AB-038-1/8		1/8
AB-038-1/4		1/4
AB-038-3/8		3/8
AB-038-1/2		1/2
AB-038-3/4		3/4

AB-039
Female brass socket



Model	Female thread	Male thread
AB-039-1/8	1/8	
AB-039-1/4	1/4	
AB-039-3/8	3/8	
AB-039-1/2	1/2	
AB-039-3/4	3/4	

AB-044
Female 4ways Y branch



Model	Female thread	Male thread
AB-044-1/8	1/8	
AB-044-1/4	1/4	
AB-044-3/8	3/8	
AB-044-1/2	1/2	
AB-044-3/4	3/4	

AB-045
Female 3ways Y branch



Model	Female thread	Male thread
AB-045-1/8	1/8	
AB-045-1/4	1/4	
AB-045-3/8	3/8	
AB-045-1/2	1/2	
AB-045-3/4	3/4	

AB-046
F-M 3ways Y branch



Model	Female thread	Male thread
AB-046-1/8-1/8	1/8	1/8
AB-046-1/4-1/4	1/4	1/4
AB-046-3/8-3/8	3/8	3/8
AB-046-1/2-1/2	1/2	1/2
AB-046-3/4-3/4	3/4	3/4

How to order:

AB - 048 - 1/4 - 6

● Brass fitting

● Type

● Male thread
1/8
1/4
3/8
1/2
3/4
1

● Hose I.D.
4
5
6.5
8
10
12

AB-047
Male hose barb elbow



Model	Male thread	Hose I.D.
AB-047-1/8-4	1/8	4
AB-047-1/4-5	1/4	5
AB-047-3/8-6.5	3/8	6.5
AB-047-1/2-8	1/2	8
AB-047-3/4-10	3/4	10
AB-047-1-12	1	12

AB-048
Male hose barb



Model	Male thread	Hose I.D.
AB-048-1/8-4	1/8	4
AB-048-1/4-5	1/4	5
AB-048-3/8-6.5	3/8	6.5
AB-048-1/2-8	1/2	8
AB-048-3/4-10	3/4	10
AB-048-1-12	1	12

AB-050
Female hose barb



Model	Hose I.D.
AB-050-4	4
AB-050-5	5
AB-050-6.5	6.5
AB-050-8	8
AB-050-10	10
AB-050-12	12

AB-053
Hose barb nipple



Model	Male thread	Hose I.D.
AB-053-4		4
AB-053-5		5
AB-053-6.5		6.5
AB-053-8		8
AB-053-10		10
AB-053-12		12

AB-054
Hose barb Tee branch



Model	Male thread	Hose I.D.
AB-054-4		4
AB-054-5		5
AB-054-6.5		6.5
AB-054-8		8
AB-054-10		10
AB-054-12		12

AB-055
Hose barb Y branch



Model	Male thread	Hose I.D.
AB-055-4		4
AB-055-5		5
AB-055-6.5		6.5
AB-055-8		8
AB-055-10		10
AB-055-12		12

AB-056
Hose barb cross



Model	Male thread	Hose I.D.
AB-056-4		4
AB-056-5		5
AB-056-6.5		6.5
AB-056-8		8
AB-056-10		10
AB-056-12		12

AB-057
Brass ferrule fitting



Model	Male thread	Hose O.D.
AB-057-1/8-6	1/8	6
AB-057-1/4-8	1/4	8
AB-057-3/8-10	3/8	10
AB-057-1/2-12	1/2	12
AB-057-3/4-14	3/4	14

AB-074
Brass ferrule elbow




Model	Female thread	Hose O.D.
AB-074-6		6
AB-074-8		8
AB-074-10		10
AB-074-12		12
AB-074-14		14
AB-074-16		16

AB-075
Brass swivel connector



Model	Male thread	Hose O.D.	Hose I.D.
AB-075-1/8-6	1/8	6	4
AB-075-1/4-8	1/4	8	5
AB-075-3/8-10	3/8	10	6.5
AB-075-1/2-12	1/2	12	8
AB-075-3/4-14	3/4	14	10
AB-075-1-16	1	16	12

How to order:



AB-001N
Brass male elbow



Model	Female thread	Male thread
AB-001N-1/8		1/8
AB-001N-1/4		1/4
AB-001N-3/8		3/8
AB-001N-1/2		1/2
AB-001N-3/4		3/4

AB-002N
Brass female elbow



Model	Female thread	Male thread
AB-002N-1/8	1/8	
AB-002N-1/4	1/4	
AB-002N-3/8	3/8	
AB-002N-1/2	1/2	
AB-002N-3/4	3/4	

AB-003N
Brass F-M elbow



Model	Female thread	Male thread
AB-003N-1/8-1/8	1/8	1/8
AB-003N-1/4-1/4	1/4	1/4
AB-003N-3/8-3/8	3/8	3/8
AB-003N-1/2-1/2	1/2	1/2
AB-003N-3/4-3/4	3/4	3/4

AB-007N
Brass Tee branch



Model	Female thread	Male thread
AB-007N-1/8		1/8
AB-007N-1/4		1/4
AB-007N-3/8		3/8
AB-007N-1/2		1/2
AB-007N-3/4		3/4

AB-008N
Brass female Tee branch



Model	Female thread	Male thread
AB-008N-1/8		1/8
AB-008N-1/4		1/4
AB-008N-3/8		3/8
AB-008N-1/2		1/2
AB-008N-3/4		3/4

AB-009N
Brass F-F-M Tee branch



Model	Female thread	Male thread
AB-009N-1/8-1/8	1/8	1/8
AB-009N-1/4-1/4	1/4	1/4
AB-009N-3/8-3/8	3/8	3/8
AB-009N-1/2-1/2	1/2	1/2
AB-009N-3/4-3/4	3/4	3/4

AB-010N
Brass F-M-F Tee branch



Model	Female thread	Male thread
AB-010N-1/8-1/8	1/8	1/8
AB-010N-1/4-1/4	1/4	1/4
AB-010N-3/8-3/8	3/8	3/8
AB-010N-1/2-1/2	1/2	1/2
AB-010N-3/4-3/4	3/4	3/4

AB-011N
Brass M-F-M Tee branch



Model	Female thread	Male thread
AB-011N-1/8-1/8	1/8	1/8
AB-011N-1/4-1/4	1/4	1/4
AB-011N-3/8-3/8	3/8	3/8
AB-011N-1/2-1/2	1/2	1/2
AB-011N-3/4-3/4	3/4	3/4

AB-032N
Male double nipple



Model	Female thread	Male thread
AB-032N-1/8		1/8
AB-032N-1/4		1/4
AB-032N-3/8		3/8
AB-032N-1/2		1/2
AB-032N-3/4		3/4

AB-033N
Male reducer nipple



Model	Male(1) thread	Male(2) thread
AB-033N-1/8-1/4	1/8	1/4
AB-033N-1/4-3/8	1/4	3/8
AB-033N-3/8-1/2	3/8	1/2
AB-033N-1/2-3/4	1/2	3/4

AB-034N
Brass F-M adapter



Model	Female thread	Male thread
AB-034N-1/8-1/8	1/8	1/8
AB-034N-1/4-1/4	1/4	1/4
AB-034N-3/8-3/8	3/8	3/8
AB-034N-1/2-1/2	1/2	1/2
AB-034N-3/4-3/4	3/4	3/4

AB-035N
Brass F-M reducer



Model	Female thread	Male thread
AB-035N-1/8-1/4	1/8	1/4
AB-035N-1/4-3/8	1/4	3/8
AB-035N-3/8-1/2	3/8	1/2
AB-035N-1/2-3/4	1/2	3/4

AB-036N
Brass Hex.socket plug



Model	Female thread	Male thread
AB-036N-1/8		1/8
AB-036N-1/4		1/4
AB-036N-3/8		3/8
AB-036N-1/2		1/2
AB-036N-3/4		3/4

AB-037N
Brass Hex.socket plug



Model	Female thread	Male thread
AB-037N-1/8		1/8
AB-037N-1/4		1/4
AB-037N-3/8		3/8
AB-037N-1/2		1/2
AB-037N-3/4		3/4

AB-039N
Brass female socket



Model	Female thread	Male thread
AB-039N-1/8	1/8	
AB-039N-1/4	1/4	
AB-039N-3/8	3/8	
AB-039N-1/2	1/2	
AB-039N-3/4	3/4	

AB-048N
Brass hose barb



Model	Male thread	Hose I.D.
AB-048N-1/8-4	1/8	4
AB-048N-1/4-5	1/4	5
AB-048N-3/8-6.5	3/8	6.5
AB-048N-1/2-8	1/2	8
AB-048N-3/4-10	3/4	10
AB-048N-1-12	1	12

AB-086N
Extended F-M adapter



Model	Female thread	Male thread
AB-086N-1/8-1/8	1/8	1/8
AB-086N-1/4-1/4	1/4	1/4
AB-086N-3/8-3/8	3/8	3/8
AB-086N-1/2-1/2	1/2	1/2
AB-086N-3/4-3/4	3/4	3/4

How to order:

RPC - 1/4 - 6x4

- Type
RPC
RPL
RPM
RPB
⋮
- Male thread
1/8
1/4
3/8
1/2
3/4
1
- Hose O.D.x I.D.
6x4
8x5
10x6.5
12x8
14x10
16x12

RPC
Male straight




Model	Male thread	Hose O.D.	Hose I.D.
RPC-1/8-6x4	1/8	6	4
RPC-1/4-8x5	1/4	8	5
RPC-3/8-10x6.5	3/8	10	6.5
RPC-1/2-12x8	1/2	12	8
RPC-3/4-14x10	3/4	14	10
RPC-1-16x12	1	16	12

RPL
Male swivel 90°elbow



Model	Male thread	Hose O.D.	Hose I.D.
RPL-1/8-6x4	1/8	6	4
RPL-1/4-8x5	1/4	8	5
RPL-3/8-10x6.5	3/8	10	6.5
RPL-1/2-12x8	1/2	12	8
RPL-3/4-14x10	3/4	14	10
RPL-1-16x12	1	16	12

RPLW
Male 90°elbow



Model	Male thread	Hose O.D.	Hose I.D.
RPLW-1/8-6x4	1/8	6	4
RPLW-1/4-8x5	1/4	8	5
RPLW-3/8-10x6.5	3/8	10	6.5
RPLW-1/2-12x8	1/2	12	8
RPLW-3/4-14x10	3/4	14	10
RPLW-1-16x12	1	16	12

RPU
Straight fitting



Model	Hose O.D.	Hose I.D.
RPU-6x4	6	4
RPU-8x5	8	5
RPU-10x6.5	10	6.5
RPU-12x8	12	8
RPU-14x10	14	10
RPU-16x12	16	12

RPM
Bulkhead straight



Model	Hose O.D.	Hose I.D.
RPM-6x4	6	4
RPM-8x5	8	5
RPM-10x6.5	10	6.5
RPM-12x8	12	8
RPM-14x10	14	10
RPM-16x12	16	12

RPV
90°elbow



Model	Hose O.D.	Hose I.D.
RPV-6x4	6	4
RPV-8x5	8	5
RPV-10x6.5	10	6.5
RPV-12x8	12	8
RPV-14x10	14	10
RPV-16x12	16	12

RPE
Tee branch



Model	Hose O.D.	Hose I.D.
RPE-6x4	6	4
RPE-8x5	8	5
RPE-10x6.5	10	6.5
RPE-12x8	12	8
RPE-14x10	14	10
RPE-16x12	16	12

RPB
Male Tee branch



Model	Male thread	Hose O.D.	Hose I.D.
RPB-1/8-6x4	1/8	6	4
RPB-1/4-8x5	1/4	8	5
RPB-3/8-10x6.5	3/8	10	6.5
RPB-1/2-12x8	1/2	12	8
RPB-3/4-14x10	3/4	14	10
RPB-1-16x12	1	16	12

RPB-G
Male Tee branch with o ring



Model	Male thread	Hose O.D.	Hose I.D.
RPB-G-1/8-6x4	1/8	6	4
RPB-G-1/4-8x5	1/4	8	5
RPB-G-3/8-10x6.5	3/8	10	6.5
RPB-G-1/2-12x8	1/2	12	8
RPB-G-3/4-14x10	3/4	14	10
RPB-G-1-16x12	1	16	12

RPH
Male banjo fitting



Model	Male thread	Hose O.D.	Hose I.D.
RPH-1/8-6x4	1/8	6	4
RPH-1/4-8x5	1/4	8	5
RPH-3/8-10x6.5	3/8	10	6.5
RPH-1/2-12x8	1/2	12	8
RPH-3/4-14x10	3/4	14	10
RPH-1-16x12	1	16	12

RPZA
Cross fitting



Model	Hose O.D.	Hose I.D.
RPZA-6x4	6	4
RPZA-8x5	8	5
RPZA-10x6.5	10	6.5
RPZA-12x8	12	8
RPZA-14x10	14	10
RPZA-16x12	16	12

How to order:

FPC - 1/4 - 1/4

- Type
FPC
FPL
FPV
FPE
⋮
- Male thread
1/8
1/4
3/8
1/2
3/4
1
- Hose O.D.
6
8
10
12
14
16

FPB Brass ferrule
compression male Tee branch



Model	Male thread	Hose O.D.
FPB-1/8-6	1/8	6
FPB-1/4-8	1/4	8
FPB-3/8-10	3/8	10
FPB-1/2-12	1/2	12
FPB-3/4-14	3/4	14
FPB-1-16	1	16

FPC Brass ferrule
compression male straight



Model	Male thread	Hose O.D.
FPC-1/8-6	1/8	6
FPC-1/4-8	1/4	8
FPC-3/8-10	3/8	10
FPC-1/2-12	1/2	12
FPC-3/4-14	3/4	14
FPC-1-16	1	16

FPCF Brass ferrule
compression female straight



Model	Hose O.D.
FPCF-6	6
FPCF-8	8
FPCF-10	10
FPCF-12	12
FPCF-14	14
FPCF-16	16

FPD Brass ferrule
compression male Tee branch



Model	Male thread	Hose O.D.
FPD-1/8-6	1/8	6
FPD-1/4-8	1/4	8
FPD-3/8-10	3/8	10
FPD-1/2-12	1/2	12
FPD-3/4-14	3/4	14
FPD-1-16	1	16

FPE Brass ferrule
compression Tee branch



Model	Hose O.D.
FPE-6	6
FPE-8	8
FPE-10	10
FPE-12	12
FPE-14	14
FPE-16	16

FPL Brass ferrule
compression male elbow



Model	Male thread	Hose O.D.
FPL-1/8-6	1/8	6
FPL-1/4-8	1/4	8
FPL-3/8-10	3/8	10
FPL-1/2-12	1/2	12
FPL-3/4-14	3/4	14
FPL-1-16	1	16

FPM Brass ferrule
compression bulkhead straight



Model	Hose O.D.
FPM-1/8-6	6
FPM-1/4-8	8
FPM-3/8-10	10
FPM-1/2-12	12
FPM-3/4-14	14
FPM-1-16	16

FPU Brass ferrule
compression straight



Model	Hose O.D.
FPU-6	6
FPU-8	8
FPU-10	10
FPU-12	12
FPU-14	14
FPU-16	16

FPV Brass ferrule
compression elbow




Model	Hose O.D.
FPV-6	6
FPV-8	8
FPV-10	10
FPV-12	12
FPV-14	14
FPV-16	16

FPZA Brass ferrule
compression cross



Model	Hose O.D.
FPZA-6	6
FPZA-8	8
FPZA-10	10
FPZA-12	12
FPZA-14	14
FPZA-16	16

How to order:



CS-032
Steel double nipple



Model	Female thread	Male thread
CS-032-1/8		1/8
CS-032-1/4		1/4
CS-032-3/8		3/8
CS-032-1/2		1/2
CS-032-3/4		3/4

CS-034
Steel F-M adapter



Model	Female thread	Male thread
CS-034-1/8		1/8
CS-034-1/4		1/4
CS-034-3/8		3/8
CS-034-1/2		1/2
CS-034-3/4		3/4

CS-035
Steel F-M reducer



Model	Female thread	Male thread
CS-035-1/8-1/8	1/8	1/8
CS-035-1/4-1/4	1/4	1/4
CS-035-3/8-3/8	3/8	3/8
CS-035-1/2-1/2	1/2	1/2
CS-035-3/4-3/4	3/4	3/4

CS-036
Steel Hex.socket plug



Model	Female thread	Male thread
CS-036-1/8		1/8
CS-036-1/4		1/4
CS-036-3/8		3/8
CS-036-1/2		1/2
CS-036-3/4		3/4

CS-037
Steel Hex.socket plug



Model	Female thread	Male thread
CS-037-1/8		1/8
CS-037-1/4		1/4
CS-037-3/8		3/8
CS-037-1/2		1/2
CS-037-3/4		3/4

CS-038
Steel Hex.plug



Model	Female thread	Male thread
CS-038-1/8		1/8
CS-038-1/4		1/4
CS-038-3/8		3/8
CS-038-1/2		1/2
CS-038-3/4		3/4

CS-039
Steel female socket



Model	Female thread	Male thread
CS-039-1/8	1/8	
CS-039-1/4	1/4	
CS-039-3/8	3/8	
CS-039-1/2	1/2	
CS-039-3/4	3/4	

CS-041
Steel bulkhead fitting



Model	Female thread	Male thread
CS-041-1/8-1/4	1/8	1/4
CS-041-1/4-3/8	1/4	3/8
CS-041-3/8-1/2	3/8	1/2
CS-041-1/2-3/4	1/2	3/4

CS-8054
Female five ports



Model	Female thread	Male thread
CS-8054-1/4	1/4	
CS-8054-3/8	3/8	
CS-8054-1/2	1/2	
CS-8054-3/4	3/4	

CS-8057
Five ports adpater



Model	Female thread	Male thread
CS-8057-1/4-1/4	1/4	1/4
CS-8057-3/8-3/8	3/8	3/8
CS-8057-1/2-1/2	1/2	1/2
CS-8057-3/4-3/4	3/4	3/4

CS-8059
Male five ports



Model	Female thread	Male thread
CS-8059-1/4		1/4
CS-8059-3/8		3/8
CS-8059-1/2		1/2
CS-8059-3/4		3/4

CS-8060
Female six ports



Model	Female thread	Male thread
CS-8060-1/4	1/4	
CS-8060-3/8	3/8	
CS-8060-1/2	1/2	
CS-8060-3/4	3/4	

CS-8061
Male six ports



Model	Female thread	Male thread
CS-8061-1/4-1/4	1/4	1/4
CS-8061-3/8-3/8	3/8	3/8
CS-8061-1/2-1/2	1/2	1/2
CS-8061-3/4-3/4	3/4	3/4

CS-8069
Male six ports



Model	Female thread	Male thread
CS-8069-1/4-1/4	1/4	1/4
CS-8069-3/8-3/8	3/8	3/8
CS-8069-1/2-1/2	1/2	1/2
CS-8069-3/4-3/4	3/4	3/4

CS-8071
Steel tri-branch 90°



Model	Female thread	Male thread
CS-8071-1/4		1/4
CS-8071-3/8		3/8
CS-8071-1/2		1/2
CS-8071-3/4		3/4

CS-8072
Steel Tee branch



Model	Female thread	Male thread
CS-8072-1/4		1/4
CS-8072-3/8		3/8
CS-8072-1/2		1/2
CS-8072-3/4		3/4

CS-8073
Steel Tri-branch 120°



Model	Male(1) thread	Male(2) thread
CS-8073-1/4-3/8	1/4	3/8
CS-8073-3/8-1/2	3/8	1/2
CS-8073-1/2-3/4	1/2	3/4

CS-8074
Steel elbow with nut



Model	Female thread	Male thread
CS-8074-1/4		1/4
CS-8074-3/8		3/8
CS-8074-1/2		1/2
CS-8074-3/4		3/4

CS-8077
Steel round elbow



Model	Male(1) thread	Male(2) thread
CS-8077-1/4-3/8	1/4	3/8
CS-8077-3/8-1/2	3/8	1/2
CS-8077-1/2-3/4	1/2	3/4

CS-8078
Steel long Tee branch



Model	Female thread	Male thread
CS-8078-1/4		1/4
CS-8078-3/8		3/8
CS-8078-1/2		1/2
CS-8078-3/4		3/4

CS-8081N
Steel long tri-branch 120°



Model	Female thread	Male thread
CS-8079-1/4		1/4
CS-8079-3/8		3/8
CS-8079-1/2		1/2
CS-8079-3/4		3/4

CS-8081
Long tri-branch 120° with nut



Model	Female thread	Male thread
CS-8081-1/4		1/4
CS-8081-3/8		3/8
CS-8081-1/2		1/2
CS-8081-3/4		3/4

CS-8083N
Steel elbow with nut



Model	Female thread	Male thread
CS-8083N-1/4		1/4
CS-8083N-3/8		3/8
CS-8083N-1/2		1/2
CS-8083N-3/4		3/4

CS-8083
Steel long elbow



Model	Female thread	Male thread
CS-8083-1/4		1/4
CS-8083-3/8		3/8
CS-8083-1/2		1/2
CS-8083-3/4		3/4

CS-8087
Steel Arc elbow



Model	Female thread	Male thread
CS-8087-1/4		1/4
CS-8087-3/8		3/8
CS-8087-1/2		1/2
CS-8087-3/4		3/4

CS-8092
Steel tri-branch with nut



Model	Female thread	Male thread
CS-8092-1/4		1/4
CS-8092-3/8		3/8
CS-8092-1/2		1/2
CS-8092-3/4		3/4

How to order:

CV - 03 - 1/8

● Brass fitting

● Type

● Male thread

1/8
1/4
3/8
1/2
3/4
1

CV-01
One way check valve



Model	Female thread	Male thread
CV-01-1/8	1/8	
CV-01-1/4	1/4	
CV-01-3/8	3/8	
CV-01-1/2	1/2	
CV-01-3/4	3/4	

CV-03
Brass check valve



Model	Female thread	Male thread
CV-03-1/4		1/4
CV-03-3/8		3/8
CV-03-1/2		1/2
CV-03-3/4		3/4
CV-03-1		1

CV-04
Brass check valve



Model	Male thread	Hose O.D.
CV-04-1/4	1/4	
CV-04-3/8	3/8	
CV-04-1/2	1/2	
CV-04-3/4	3/4	
CV-04-1	1	

CV-05
Brass check valve



Model	Male thread	Hose O.D.
CV-05-1/4	1/4	
CV-05-3/8	3/8	
CV-05-1/2	1/2	
CV-05-3/4	3/4	
CV-05-1	1	

CV-06
Brass check valve



Model	Male thread	Hose I.D.
CV-06-1/4	1/4	
CV-06-3/8	3/8	
CV-06-1/2	1/2	
CV-06-3/4	3/4	
CV-06-1	1	

CV-07
Brass foot valve



Model	Female thread	Male thread
CV-07-1/4	1/4	
CV-07-3/8	3/8	
CV-07-1/2	1/2	
CV-07-3/4	3/4	
CV-07-1	1	

CV-07F
Brass foot valve with mesh



Model	Female thread	Male thread
CV-07F-1/4	1/4	
CV-07F-3/8	3/8	
CV-07F-1/2	1/2	
CV-07F-3/4	3/4	
CV-07F-1	1	

CV-07FB
Brass foot valve with mesh



Model	Female thread	Hose I.D.
CV-07FB-1/4	1/4	
CV-07FB-3/8	3/8	
CV-07FB-1/2	1/2	
CV-07FB-3/4	3/4	
CV-07FB-1	1	

CV-08
Brass check valve



Model	Female thread	Male thread
CV-08-1/4	1/4	
CV-08-3/8	3/8	
CV-08-1/2	1/2	
CV-08-3/4	3/4	
CV-08-1	1	

CV-09
Brass foot valve



Model	Female thread	Male thread
CV-09-1/4	1/4	
CV-09-3/8	3/8	
CV-09-1/2	1/2	
CV-09-3/4	3/4	
CV-09-1	1	

CV-10
Brass exhaust valve



Model	Male thread	Hose I.D.
CV-10-1/4	1/4	
CV-10-3/8	3/8	
CV-10-1/2	1/2	
CV-10-3/4	3/4	
CV-10-1	1	

CV-12
Steel check valve



Model	Female thread	Male thread
CV-12-1/4		1/4
CV-12-3/8		3/8
CV-12-1/2		1/2
CV-12-3/4		3/4
CV-12-1		1

YF-25
Brass Y drainer



Model	Female thread	Male thread
YF-25-1/4	1/4	
YF-25-3/8	3/8	
YF-25-1/2	1/2	
YF-25-3/4	3/4	
YF-25-1	1	

How to order:

AC - 002 - 1/4

● Brass fitting

● Type

● Hose O.D.

1/4

3/8

6

8

10

12

AC-001

Copper cap



Model	Hose O.D.
AC-001-1/4	1/4
AC-001-3/8	3/8
AC-001-6	6
AC-001-8	8
AC-001-10	10
AC-001-12	12

AC-002

Copper socket



Model	Hose O.D.
AC-002-1/4	1/4
AC-002-3/8	3/8
AC-002-6	6
AC-002-8	8
AC-002-10	10
AC-002-12	12

AC-003

Copper reducer



Model	Hose O.D.
AC-003-1/4	1/4
AC-003-3/8	3/8
AC-003-6	6
AC-003-8	8
AC-003-10	10
AC-003-12	12

AC-004

Copper U elbow



Model	Hose O.D.
AC-004-1/4	1/4
AC-004-3/8	3/8
AC-004-6	6
AC-004-8	8
AC-004-10	10
AC-004-12	12

AC-005

Copper U elbow



Model	Hose O.D.
AC-005-1/4	1/4
AC-005-3/8	3/8
AC-005-6	6
AC-005-8	8
AC-005-10	10
AC-005-12	12

AC-006
Copper U elbow socket



Model	Hose O.D.
AC-006-1/4	1/4
AC-006-3/8	3/8
AC-006-6	6
AC-006-8	8
AC-006-10	10
AC-006-12	12

AC-007
Copper plug-in U elbow



Model	Hose O.D.
AC-007-1/4	1/4
AC-007-3/8	3/8
AC-007-6	6
AC-007-8	8
AC-007-10	10
AC-007-12	12

AC-008
Copper U elbow



Model	Hose O.D.
AC-008-1/4	1/4
AC-008-3/8	3/8
AC-008-6	6
AC-008-8	8
AC-008-10	10
AC-008-12	12

AC-009
Copper 45°elbow socket



Model	Hose O.D.
AC-009-1/4	1/4
AC-009-3/8	3/8
AC-009-6	6
AC-009-8	8
AC-009-10	10
AC-009-12	12

AC-010
Copper 45°elbow socket



Model	Hose O.D.
AC-010-1/4	1/4
AC-010-3/8	3/8
AC-010-6	6
AC-010-8	8
AC-010-10	10
AC-010-12	12

AC-011
Copper 90°elbow



Model	Hose O.D.
AC-011-1/4	1/4
AC-011-3/8	3/8
AC-011-6	6
AC-011-8	8
AC-011-10	10
AC-011-12	12

AC-012
Copper 90°elbow socket



Model	Hose O.D.
AC-012-1/4	1/4
AC-012-3/8	3/8
AC-012-6	6
AC-012-8	8
AC-012-10	10
AC-012-12	12

AC-013
Copper 90°elbow socket



Model	Hose O.D.
AC-013-1/4	1/4
AC-013-3/8	3/8
AC-013-6	6
AC-013-8	8
AC-013-10	10
AC-013-12	12

AC-014
Copper 90°elbow socket



Model	Hose O.D.
AC-014-1/4	1/4
AC-014-3/8	3/8
AC-014-6	6
AC-014-8	8
AC-014-10	10
AC-014-12	12

AC-015
Copper reducing 90°elbow



Model	Hose O.D.
AC-015-1/4	1/4
AC-015-3/8	3/8
AC-015-6	6
AC-015-8	8
AC-015-10	10
AC-015-12	12

AC-016
Copper Tri-branch



Model	Hose O.D.
AC-016-1/4	1/4
AC-016-3/8	3/8
AC-016-6	6
AC-016-8	8
AC-016-10	10
AC-016-12	12

AC-017
Copper Tri-branch



Model	Hose O.D.
AC-017-1/4	1/4
AC-017-3/8	3/8
AC-017-6	6
AC-017-8	8
AC-017-10	10
AC-017-12	12

AC-018
Copper Tee branch



Model	Hose O.D.
AC-018-1/4	1/4
AC-018-3/8	3/8
AC-018-6	6
AC-018-8	8
AC-018-10	10
AC-018-12	12

AC-019
Copper reducing T branch



Model	Hose O.D.
AC-019-1/4	1/4
AC-019-3/8	3/8
AC-019-6	6
AC-019-8	8
AC-019-10	10
AC-019-12	12

AC-020
Copper reducing T branch



Model	Hose O.D.
AC-020-1/4	1/4
AC-020-3/8	3/8
AC-020-6	6
AC-020-8	8
AC-020-10	10
AC-020-12	12

AC-021
Copper reducing T branch



Model	Hose O.D.
AC-021-1/4	1/4
AC-021-3/8	3/8
AC-021-6	6
AC-021-8	8
AC-021-10	10
AC-021-12	12

AC-022
Copper cross



Model	Hose O.D.
AC-022-1/4	1/4
AC-022-3/8	3/8
AC-022-6	6
AC-022-8	8
AC-022-10	10
AC-022-12	12

AC-023
Copper reducing cross



Model	Hose O.D.
AC-023-1/4	1/4
AC-023-3/8	3/8
AC-023-6	6
AC-023-8	8
AC-023-10	10
AC-023-12	12

AC-024
Copper curving pipe



Model	Hose O.D.
AC-024-1/4	1/4
AC-024-3/8	3/8
AC-024-6	6
AC-024-8	8
AC-024-10	10
AC-024-12	12

AC-025
Copper bridge



Model	Hose O.D.
AC-025-1/4	1/4
AC-025-3/8	3/8
AC-025-6	6
AC-025-8	8
AC-025-10	10
AC-025-12	12

AC-026
Copper bridge T branch



Model	Hose O.D.
AC-026-1/4	1/4
AC-026-3/8	3/8
AC-026-6	6
AC-026-8	8
AC-026-10	10
AC-026-12	12

AC-027
Copper Tee branch




Model	Hose O.D.
AC-027-1/4	1/4
AC-027-3/8	3/8
AC-027-6	6
AC-027-8	8
AC-027-10	10
AC-027-12	12

AC-028
Copper reducer



Model	Hose O.D.
AC-028-1/4	1/4
AC-028-3/8	3/8
AC-028-6	6
AC-028-8	8
AC-028-10	10
AC-028-12	12

AC-029
Copper female plug



Model	Hose O.D.
AC-029-1/4	1/4
AC-029-3/8	3/8
AC-029-6	6
AC-029-8	8
AC-029-10	10
AC-029-12	12

AC-030
Copper plug



Model	Hose O.D.
AC-030-1/4	1/4
AC-030-3/8	3/8
AC-030-6	6
AC-030-8	8
AC-030-10	10
AC-030-12	12

Others

How to order:

AB - 003 - 1/8 - 1/8 - 1/4

● Brass fitting

● Type

● Female thread
1/8
1/4
3/8
1/2
3/4
1

● Male thread
1/8
1/4
3/8
1/2
3/4
1

● Hose O.D.
6
8
10
12
14
16

AC-B
Brass air chunk



Model	Female thread
AC-B-1/8	1/8
AC-B-1/4	1/4
AC-B-3/8	3/8
AC-B-1/2	1/2
AC-B-3/4	3/4

AC-C-B
Brass air chunk with clamp



Model	Hose O.D.
AC-C-B-6	6
AC-C-B-8	8
AC-C-B-10	10
AC-C-B-12	12
AC-C-B-14	14
AC-C-B-16	16

AC-C-C
Steel air chunk with clamp



Model	Hose O.D.
AC-C-C-6	6
AC-C-C-8	8
AC-C-C-10	10
AC-C-C-12	12
AC-C-C-14	14
AC-C-C-16	16

BF-M
Brass male filter



Model	Male thread
BF-M-1/8	1/8
BF-M-1/4	1/4
BF-M-3/8	3/8
BF-M-1/2	1/2
BF-M-3/4	3/4

UJ-MF-02
Universal joint



Model	Female thread	Male thread	Hose O.D.
UJ-MF-02-1/8-1/8	1/8	1/8	1/4
UJ-MF-02-1/4-1/4	1/4	1/4	3/8
UJ-MF-02-3/8-3/8	3/8	3/8	6
UJ-MF-02-1/2-1/2	1/2	1/2	8
UJ-MF-02-3/4-3/4	3/4	3/4	10
UJ-MF-02-1-1	1	1	12